

*Chambers
Crossword Pen*

User's Guide

License Agreement

READ THIS LICENSE AGREEMENT BEFORE USING THE ELECTRONIC REFERENCE. YOUR USE OF THE ELECTRONIC REFERENCE DEEMS THAT YOU ACCEPT THE TERMS OF THIS LICENSE. IF YOU DO NOT AGREE WITH THESE TERMS, YOU MAY RETURN THIS PACKAGE WITH PURCHASE RECEIPT TO THE DEALER FROM WHICH YOU PURCHASED THE ELECTRONIC REFERENCE AND YOUR PURCHASE PRICE WILL BE REFUNDED. ELECTRONIC REFERENCE means the software product and documentation found in this package and FRANKLIN means Franklin Electronic Publishers, Inc.


Limited Use License

All rights in the ELECTRONIC REFERENCE remain the property of FRANKLIN. Through your purchase, FRANKLIN grants you a personal and non-exclusive license to use this ELECTRONIC REFERENCE. You may not make any copies of the ELECTRONIC REFERENCE or of the data stored therein, whether in electronic or print format. Such copying would be in violation of applicable copyright laws. Further, you may not modify, adapt, disassemble, decompile, translate, create derivative works of, or in any way reverse engineer the ELECTRONIC REFERENCE. You may not export or re-export, directly or indirectly, the ELECTRONIC REFERENCE without compliance with appropriate governmental regulations. The ELECTRONIC REFERENCE contains Franklin's confidential and proprietary information which you agree to take adequate steps to protect from unauthorized disclosure or use. This license is effective until terminated. This license terminates immediately without notice from FRANKLIN if you fail to comply with any provision of this license.

Key Guide

Remove the cap to access the refill.

Press ▲ and ▼ to scroll backward and forward through the alphabet, ? and * when entering letters and to scroll when viewing an entry.



Twist the cap to reveal or conceal the writing tip.

Press **ON/OFF** once to turn the unit on. Thereafter, press it to return to the "ENTER a word" screen. Press and hold **ON/OFF** for a few seconds to turn the unit off.

Press ► and ◀ to move the cursor right and left.

Press **MENU** to go to the main menu where you can search for phrases, play games or flip the orientation of the screen.

Press **ENTER** to begin a search.

Getting Started


The *Chambers Crossword Pen* comes with one CR-2032 three-volt lithium battery and a Phillips screwdriver. Before you can begin using the pen, you must install the battery.

Installing the Battery

To install or replace the battery follow these instructions:

1. **Turn the product off, if necessary.**
2. **Unscrew the screw and gently remove the battery cover.**

Remove the old battery, if necessary.



Getting Started


3. **Install the new battery with the positive side facing you.**
4. **Reattach the cover and replace the screw.**

Replacing an Ink Cartridge

Your pen comes with three refills. If your pen runs out of ink, you can replace the empty ink cartridge with one of the refill cartridges. To replace an ink cartridge, follow these instructions:

1. **Turn the product off, if necessary.**
2. **Remove the cap of the pen by pulling it away from the body.**

Getting Started



The cartridge is in the cap.

3. **Hold the white plastic end of the cartridge and unscrew it to remove it.**
4. **Screw in the replacement cartridge.**
5. **Push the cap back on to the body.**

✓ Automatic Shut-off

When no key has been pressed for approximately two minutes, the unit automatically shuts off to conserve the battery. Press **ON/OFF** to turn the unit on.

Entering a Word

When you turn on the *Chambers Crossword Pen*, you see the “ENTER a word” screen. To learn how to enter a word, try entering the word *aware*.

1. **Press ON/OFF to go to the “ENTER a word” screen, if necessary.**

ENTER a word

2. **Press ▼ or ▲.**

You see A. The blinking letter marks the location of the cursor.

A

3. **Press ► to move right and enter the second letter.**

You see AA.

4. **Press ▲ or ▼ until you see AW.**

Entering a Word

AW

5. Press **▶** to move right and enter the third letter.

You see *AWA*.

AWA

6. In this example, because “A” is the third letter of the word you want, press **▶** again to move right and enter the fourth letter.

You see *AWAA*.

AWAA

7. Press **▲** or **▼** until you see *AWARD*.

AWARD

Please note that when the dictionary finds a word that

Entering a Word

matches the letters you have entered, it may try to automatically complete your word. If it is the word you are looking for, press **ENTER** to look it up. If not, use the arrow keys as indicated to continue changing and adding letters until you type the word you want.

8. Press **▶** to move right and enter the fifth letter.
9. Press **▲** or **▼** until you see *AWARE*.

AWARE

10. Press **ENTER** to look it up.

5 alert

Using the Dictionary

Use your *Chambers Crossword Pen* to help you spell-check words and find synonyms of words. Synonyms are words of similar meaning. Follow the instructions below.

1. Press **ON/OFF** to go to the “**ENTER a word**” screen, if necessary.
2. Enter letters to form a word.

MOTIVATE

To learn how to enter letters, see “Entering a Word” on page 4.

Use ▲ or ▼ to scroll through the letters. Stop when you see the letter you want. Press ► to move right and enter another letter.

Press ◀ to go back and change a letter.

Using the Dictionary

If the dictionary finds a word to match the letters you have entered, it may try to automatically complete your word. If this is not the word you want, just continue entering letters until you complete your word.

3. Press **ENTER**.

4 draw

If your word has a dictionary entry, you see the list of synonyms. Each synonym is preceded by the number of letters in that word.

If your word does not have a dictionary entry, the message “Correct word” flashes on the screen and then you see your word.

4. Use ▲ or ▼ to scroll through the list, if necessary.

Using the Dictionary

6 kindle D

The flashing arrows to the right of the screen indicate the direction in which you can scroll.

Words in the list with dictionary entries are marked with a flashing D to the right. If you want to look up synonyms for that word, press **ENTER**.

5. Press **ON/OFF** to go back to the “**ENTER a word**” screen and change your word.

Finding Letters in Words

When you scroll through the list of letters, you also have the option of entering a ? or * if you are unsure of the spelling of a word. Use ? in place of one unknown letter and * in place of zero, one or more unknown letters.

1. Press **ON/OFF** to go to the “**ENTER a word**” screen, if necessary.
2. Enter a pattern of letters and ? or *. For example, enter *con??d**.

CON??D*

To learn how to enter letters, see “Entering a Word” on page 4.

Use ▲ or ▼ to scroll through the letters. Stop when you see the letter or

Finding Letters in Words

character you want. Press ► to move right and enter another letter or character.

Press ◀ to go back and change a letter or character.

3. Press ENTER.

concede

The message “Matches” flashes on the screen and you see the list of matching entries.

If you enter a pattern that cannot be matched, the message “Sorry, can’t help” flashes on the screen and then you see your pattern.

Finding Letters in Words

4. Use ▲ or ▼ to scroll through the list.

confident

The flashing arrows to the right of the screen indicate the direction in which you can scroll. Words in the list with dictionary entries are marked with a flashing D to the right. If you want to look up synonyms for that word, press ENTER.

5. Press ON/OFF to go back to the “ENTER a word” screen and change your word.

Correcting Misspellings

If you misspell a word or it is not in this dictionary, you see a list of corrections.

1. Press **ON/OFF** to go to the “**ENTER a word**” screen, if necessary.
2. Enter a misspelled word. For example, enter *jiraph*.

JIRAPH

To learn how to enter letters, see “Entering a Word” on page 4.

Use ▲ or ▼ to scroll through the letters. Stop when you see the letter or character you want. Press ► to move right and enter another letter or character. Press ◀ to go back and change a letter or character.

3. Press **ENTER**.

graph

The message “Correction list”

Correcting Misspellings

flashes on the screen and you see the list of possible corrections.

If you see the message “Sorry, can’t help”, this means no good alternatives were found. Press ◀ to return to the “ENTER a word” screen and change your word.

4. Use ▲ or ▼ to scroll through this list.

giraffe

The flashing arrows to the right of the screen indicate the direction in which you can scroll. Words in the correction list with dictionary entries are marked with a flashing D to the right of the screen. If you want to look up synonyms for that word, press **ENTER**.

5. Press **ON/OFF** to go back to the “ENTER a word” screen and change your word.

Using the Menu

The main menu of the *Chambers Crossword Pen* enables you to search for phrases, play games and flip the orientation of the screen. To select a menu item, press **MENU**, press ▲ or ▼ until the menu item you want is on the screen, then press **ENTER** to select it.

Anagram Solver

Anagram Solver takes a series of entered letters and displays a list of words using any combination of those letters.

1. Press **ON/OFF**.
2. Press **MENU**.
3. Press **ENTER** to select *Anagram Solver*.
4. Enter a word.

To enter letters, press ▲ or ▼ to scroll to the letter you

Using the Menu

want. Press ► to add another letter.

SGEINSL

5. Press **ENTER**.

The message “Anagrams” flashes on the screen and then you see the list of anagrams.

singles

6. Use ▲ or ▼ to scroll through the list.

Press **ENTER** to see the dictionary entry, when there is a flashing D at the right of the screen. Then press ◀ to return to the list of anagrams.

7. Press **ON/OFF** to return to the “**ENTER a word**” screen.

Using the Menu

Second Guess

Second Guess takes an entered word and displays a list of words that differ from the entered word by one letter.

1. Press **ON/OFF**.
2. Press **MENU**.
3. Press ▼ until you see ***Second Guess*** and then press **ENTER**.
4. Enter a word.

To enter letters, press ▲ or ▼ to scroll to the letter you want. Press ► to add another letter.

TRIED

Using the Menu

5. Press **ENTER**.

The message “More list” flashes on the screen and then you see the list of words. The changed letter is underlined.

oried

6. Use ▲ or ▼ to scroll through the list.

Press **ENTER** to see the dictionary entry, when there is a flashing D at the right of the screen. Then press ◀ to return to the “More list”.

7. Press **ON/OFF** to return to the “ENTER a word” screen.

Using the Menu

Phrases

You can find a list of phrases that use a word you enter.

1. Press **ON/OFF**.
2. Press **MENU**.
3. Press **▼** until you see *Phrases* and then press **ENTER**.
4. Enter a word.

To enter letters, press **▲** or **▼** to scroll to the letter you want. Press **▶** to add another letter.

SPEED

5. Press **ENTER**.

The message “Phrases” flashes on the screen and then you see the list of phrases using your word.

Using the Menu

at full speed

6. Use **▲** or **▼** to scroll through the list.

Press **ENTER** to see the dictionary entry, when there is a flashing **D** at the right of the screen. Press **◀** to return to the entry screen and change your word.

7. Press **ON/OFF** when done.
✓ From the “**ENTER a word**” screen

You can also enter a word at the “**ENTER a word**” screen, press **MENU**, use **▼** to highlight *Phrases* and press **ENTER**.

Using the Menu

Jumble Game

Jumble Game asks you to rearrange letters to form a word. A series of letters appears on the screen for you to rearrange. The first letter blinks, indicating the location of the cursor.

1. Press **ON/OFF**.
2. Press **MENU**.
3. Press ▼ until you see *Jumble Game* and then press **ENTER**.

A jumbled word appears on the screen.

RPY

4. **Rearrange the letters to form the correct word.**
Press ► or ◀ to move the cursor right or left. Press ▲

Using the Menu

to swap the blinking letter with the letter on its right. The right-most letter will be swapped with the left-most letter. Press ▼ to swap the blinking letter with the letter on its left. The left-most letter will be swapped with the right-most letter.

PRY

5. **Press ENTER.**
If the rearranged letters do not make a word in this dictionary, you see the message “No, try again.” You have three chances to solve the jumble.
6. **To try another word, press ► or ENTER.**
7. **Press ON/OFF when done.**

Using the Menu

Crossword Quiz

Crossword Quiz asks you to guess a mystery word based on a provided clue.

1. Press **ON/OFF**.
2. Press **MENU**.
3. Press **▼** until you see *Crossword Quiz* and then press **ENTER**.

The clue flashes on the screen, then the mystery word.

supervise

insp?ct

Using the Menu

Missing letters are replaced by a ?. To see the clue again, press **ENTER** before you replace all the ?s.

4. Use **▲** or **▼** to pick the mystery letter.

i n s p E c t

Use **▶** or **◀** to move the cursor to another ?, if necessary.

5. Press **ENTER** when all the ?s are replaced with letters. You have three chances to guess the mystery word.
6. To try another word, press **▶** or **ENTER**.
7. Press **ON/OFF** when done.

Flip Orientation

Depending on how you hold the pen or whether you are left- or right-handed, you may want to change the orientation of the screen.

1. Press **ON/OFF**.
2. Press **MENU**.
3. Press **▼** until you see **Flip Orientation** and then press **ENTER** to flip the orientation upside-down.

This unit may change operating modes due to Electro-static Discharge. Normal operation of this unit can be re-established by pressing the reset key, **ON/OFF**, or by removing/replacing batteries.

Model CWR-52 *Chambers Crossword Pen*

Batteries 1 X CR-2032 V Lithium
ISBN 1-59074-258-3

Cleaning and Storage

To clean, spray a mild glass cleaner onto a cloth and wipe the surface of the LCD. Do not spray liquids directly on this product. Do not use or store this product in extreme or prolonged heat, cold, humidity or other adverse conditions.

© 2004 Franklin Electronic Publishers (UK) Ltd. 12 Windmill Business Village, Brooklands Close, Sunbury-on-Thames, Middlesex, England TW16 7DY. All rights reserved.

FCC Tested To Comply With FCC Standards

FOR HOME OR OFFICE USE

Chambers Concise Crossword Dictionary © 2004 Chambers Harrap Publishers Ltd. All rights reserved.

U.S. Patents 4,830,618; 4,891,775; 5,113,340; 5,218,536; 5,396,606; 5,249,965

For the U.S. Limited Warranty in English visit www.Franklin.com/service.

Limited Warranty (EU and Switzerland)

This product, excluding batteries and liquid crystal display (LCD), is guaranteed by Franklin for a period of two years from the date of purchase. It will be repaired or replaced with an equivalent product (at Franklin's option) free of charge for any defect due to faulty workmanship or materials. Products purchased outside the European Union and Switzerland that are returned under warranty should be returned to the original vendor with proof of purchase and description of fault. Charges will be made for all repairs unless valid proof of purchase is provided. This warranty explicitly excludes defects due to misuse, accidental damage, or wear and tear. This guarantee does not affect the consumer's statutory rights.

ESP-28000-00
Rev A

Limited Warranty (outside U.S., EU and Switzerland)

This product, excluding batteries and liquid crystal display (LCD), is guaranteed by Franklin for a period of one year from the date of purchase. It will be repaired or replaced with an equivalent product (at Franklin's option) free of charge for any defect due to faulty workmanship or materials. Products purchased outside the United States, the European Union and Switzerland that are returned under warranty should be returned to the original vendor with proof of purchase and description of fault. Charges will be made for all repairs unless valid proof of purchase is provided. This warranty explicitly excludes defects due to misuse, accidental damage, or wear and tear. This guarantee does not affect the consumer's statutory rights.

Franklin[®]
Electronic Publishers
www.franklin.com/uk